

# Introduction

Thank you for purchasing your TRILAB DeltiQ 2 printer. Before you begin using your new machine, please familiarize yourself with this manual. We wrote it so that you can avoid damage due to malpractices and maximize the quality of your future prints.

Unless otherwise stated, all of the instructions herein are simple and do not require excessive force. Should you encounter a procedure where your muscles tense up greatly and nothing happens, please consult this manual again.

In the case that this manual doesn't answer your question(s), please contact our support team at [support@trilab.cz](mailto:support@trilab.cz).

## Safety instructions

Your safety and well being is our priority, so please follow these instructions when using your printer:

- The printer shall only be operated by trained personnel.
- The printer shall be operated only under supervision. In the event of a malfunction or unusual printer behavior, stop printing and shut down the printer.
- Power to the printer is supplied by high voltage. Always turn off the printer and unplug the power cord before accessing the power supply.
- The printer contains moving parts and therefore, do not interfere with the printer during printing. The printer can start moving without any notice and can cause injury.

# Emergency STOP

The printer is equipped with a red emergency shut off switch – *EMERGENCY STOP*, placed at the top of the printer. Once pushed, this switch deactivates any ongoing operation, such as printing, disconnecting heated components, and stopping printer movement. After a short pause, the print head cooling fan will reactivate should the head remain hot. This function is to prevent the head from clogging and therefore, do not turn off the printer immediately after using the *EMERGENCY STOP* switch during printing.



At the touch of a button, the printer completely restarts and is ready to operate. It is necessary however, to remove the interrupted print from the pad and prepare the pad again. In any event of abnormal printer behavior, damage or parts separation, please contact your service representative.

# Exclusion of liability






Please carefully read the contents of this installation and user manual. Failure to do so may result in poor quality results, damage to the TRILAB DeltiQ 2 printer or in the worst case scenario, injury. Always make sure that anyone using this 3D printer fully understands the contents of this manual is able to use this TRILAB DeltiQ 2 safely and optimally.

The conditions or methods used to assemble, handle, store, use or dispose of this equipment are beyond our control and may be beyond our knowledge. Because of this and other potential reasons, we do not assume any liability and expressly disclaim any liability for loss, injury, damage or expense resulting from or in any way related to the assembly, handling, storage, use or disposal of this product.

We believe the information in this document has been obtained from reliable sources. However accurate the information may be, it is provided without any warranty, expressed or implied.

# EC Declaration of Conformity

You can open the original PDF file by clicking the preview image.

	<b>EC Declaration of Conformity</b> No. 01022020/TRILAB/DeltiQ2	
TrILAB Group s.r.o. Purkyňova 649/127 612 00 Brno Czechia		ID: 05288746 VAT ID: CZ05288746. Registered in the Commercial Register of the Regional Court in Brno, section C, file 94527.
declares that the product(s): <b>3D Printer TRILAB DeltiQ 2 and DeltiQ 2 Plus</b> meets the EC directives: 2006/42/ES on machinery, and amending Directive 95/16/EC (recast) 2004/108/ES on the approximation of the laws of the Member States relating to electromagnetic compatibility		
The conformity assessment was conducted by an authorized laboratory. Person authorised to compile the technical file: <b>FS system s.r.o., Michal Chovanec</b> Hvězdoslavova 47, 627 00 Brno ID: 29291739		
Used european norms and harmonized standards that have been used or statements in relation to which conformity is declared: EN ISO 12100 EN ISO 13857 EN 1005-3+A1 EN 1037+A1 EN 1070 EN 349+A1 EN 953+A1 EN 61000-6-4 ed. 2 EN 55011 ed. 3 EN 894-2+A1 EN 894-3+A1 EN ISO 1873-1 EN 55022 ed. 3 EN 61000-3-2 ed. 3 EN 61000-3-3 ed. 2 EN 61000-3-3 ed. 3 EN 60950-1 ed. 2 EN 5081 EN 61000-6-3 ed. 2 EN 61000-4-2 ed. 2 EN 61000-4-3 ed. 3 EN 61000-6-1 ed. 2 EN 55024 ed. 2		
In Brno, Czech Republic, 1.2.2020:		  <b>Mgr. Michal Chovanec, PhD</b> CEO, TrILAB Group s.r.o.
<b>Michal Chovanec</b> Person authorised to compile the technical file		 <b>Mgr. Michal Boháč, PhD</b> CEO, TrILAB Group s.r.o.

## Product names and important concepts

DeltiQ 2 – the basic version of the TRILAB DeltiQ 2 printer with a bowden extruder.

DeltiQ 2 Plus – an extended version of the printer. The print volume is increased to 500 mm on the Z axis (height).

TRILAB FlexPrint – a solution for printing with flexible and tough filaments. It consists of a special second extruder (swapping extruders is simple and only takes a few minutes), printer configuration and print profiles. Supplied as an optional extension, formerly known as Zesty Nimble.

TRILAB FlexPrint 2 – a new and improved solution for printing with flexible and tough filaments. It consists of a special second extruder (swapping extruders is simple and only takes a few minutes), printer configuration and print profiles. Supplied as an optional extension.

TRILAB QuadPrint – a multi-filament printing solution. It consists of a separate external Palette 2 unit, configuration files, and a portion of the multi-filament printing interface. Available as an option.

TRILAB PrintPad – a removable steel print pad. Depending on its type, it may be coated with another material (i.e. PEI).